

Schlagschrauber E 40 P
Impact Wrench

60010 92 6

MANNESMANN
DEMAG

Nr. No.	BENENNUNG	DESCRIPTION	Lager-Nr. Stock-No.	Stck. Qty.
1	Federring	lock washer	030 553 74	4
2	Zylinderschraube	cyl. Screw	030 552 74	4
3	Gehäuse	Hammer Case	60022 47 6	1
4	Aufhängeöse	frame	29932 06 6	1
5	Dichtung	Hammer Case Gasket	60022 48 6	1
6	Dichtung	sealing gasket	29932 08 6	1
7	Büchse	bushing	030 554 74	1
8	Gehäusebüchse	Hammer Case Bushing	60022 49 6	1
L	Amboss vst. Pos. Nr. 11+12	Standard Anvil Shank compl. Pos. no.11+12	60063 10 6	1
11	Federring	spring ring	030 556 74	1
12	Amboss	Standard Anvil Shank	60022 52 6	1
LM	Amboss M vst. Pos. Nr. 11+12M	Standard Anvil Shank M compl. Pos. no.11+12M	60063 11 6	1
12M	Amboss M	Standard Anvil Shank M	60063 46 6	1
LL	Amboss L vst. Pos. Nr. 11+12L	Standard Anvil Shank L compl. Pos. no.11+12L	60063 12 6	1
12L	Amboss L	Standard Anvil Shank L	60063 26 6	1
13	Nutwelle	Clutch Shaft	29932 10 6	1
14	Kupplungsfeder	spring	29932 11 6	1
15	Schaltkupplung	Clutch plate	60022 53 6	1
16	Nocken	Cam, clutch	29932 13 6	1
17	Nutwellensitz	bushing clutch	299 321 46	1
18	Schwungrad	Clutch Housing	60022 54 6	1
19	Rillenkugellager	ball bearing	29932 16 6	1
A	Griff vst. Pos. Nr. 20+(40-42)+(44-56)	Gun body Pos. no. 20+(40-42)+(44-56)	60063 09 6	1
20	Griff	housing	60022 55 6	1
21	Schraubenmutter	screw nut	29932 18 6	4
22	Federring	washer	9314 008	4
23	schraube	handle Screw	9304 031	4
24	Handgriff Halter	handle bracket	29932 19 6	1
25	Rundhandgriff	round handle	29932 20 6	1
D	Lagerschild vorn vst. Pos. Nr. 27+28	front end plate compl. Pos. no 27+28	60063 47 6	1
27	Rillenkugellager	ball bearing	60022 56 6	1
28	Lagerschild vorn	front end plate	60022 57 6	1
29	Zylinderstift	parallel pin	032 077 76	1
30	Lamelle	vane	60022 58 6	8
31	Rotor	rotor	60022 59 6	1
32	Zylinderstift	parallel pin	9315 178	1

Schlagschrauber E 40 P
Impact Wrench

60010 92 6

MANNESMANN
DEMAG

E	Lagerschild hinten vst. Pos. Nr. 33+34	rear end plate compl. Pos. no 33+34	60063 48 6	1
33	Lagerschild hinten	rear end plate	60022 69 6	1
34	Rillenkugellager	ball bearing	9357 031	1
35	Dichtung	rear gasket	29932 26 6	1
36	Schraube	screw	9304 033	5
37	Federring	washer	9314 008	5
38	Deckel	motor cover, rear	29932 28 6	1
39	Zylinder	cylinder	60022 70 6	1
40	Steuerbolzen	rotation reverser	29932 30 6	1
41	O-ring	o-ring	29932 31 6	2
42	Umschaltbüchse	reversing bushing	29932 32 6	1
43	Schalldämpfer	silencer	29932 33 6	1
44	Seeger Ring	ring	29932 35 6	1
45	Sieb	strainer	032 071 76	1
46	Ventilfeder	spring	030 533 74	1
47	Ventilkugel	steel ball	9357 939	1
48	O-Ring	o ring	29932 36 6	1
49	Anschlussnippel	reducer, air inlet	29932 37 6	1
50	Ventilstift	valve pin	29921 74 6	1
51	Ventilbüchse	valve bushing	29932 34 6	1
52	Spannhülse	clamp sleeve	9315 715	2
53	Drücker	trigger	030 238 74	1
54	Stift	pin	29932 38 6	1
55	Feder	spring	030 223 74	1
56	Gewindestift	threaded pin	29932 39 6	1
57	Walzenstift	split pin	030 213 74	1
58	Walze	roll	030 212 74	1

